

Preparation of this newsletter was financed through LTAP, a nationwide effort financed jointly in Iowa by the FHWA and the Iowa DOT. Iowa's LTAP is housed and administered at ISU's Center for Transportation Research and Education (CTRE).

The mission of Iowa's LTAP:

To foster a safe, efficient, environmentally sound transportation system by improving skills and knowledge of local transportation providers through training, technical assistance, and technology transfer, thus improving the quality of life for Iowans.

Subscriptions to *Technology News* are free. We welcome readers' comments, questions, and suggestions. To subscribe, or to obtain permission to reprint articles, contact the editor.

ISU Research Park
2901 S. Loop Drive, Ste. 3100
Ames, Iowa 50010-8632
Telephone: 515-294-8103
Fax: 515-294-0467
www.ctre.iastate.edu/

Stephen J. Andrie
Director of CTRE
andrie@iastate.edu

Duane Smith
Director of Iowa LTAP
desmith@iastate.edu

Marcia Brink
Editor
mbrink@iastate.edu

Tom McDonald
Safety Circuit Rider
tmcdonal@iastate.edu

Lori Wildeman
Program Coordinator
lwild@iastate.edu

Michele Regenold
Rebekah Bovenmyer
Brett Hansen
Contributing Writers

Any reference to a commercial organization or product in this newsletter is intended for informational purposes only and not as an endorsement. The opinions, findings, or recommendations expressed here do not necessarily reflect the views of LTAP sponsors. The materials herein are provided for general information, and neither LTAP nor its sponsors represent that these materials are adequate for the purposes of the user without appropriate expert advice. ISU makes no representations or warranties, express or implied, as to the accuracy of any information herein and disclaims liability for any inaccuracies.

Iowa State University and the Center for Transportation Research and Education provide equal opportunities and comply with requirements of the Americans with Disabilities Act in programs and employment. Call the Affirmative Action Office, 515-294-7612, to report discrimination.

Installing soil nails

Following is a general description of the soil nailing process. (Begin at the top of the wall and work down.)

1. Excavate a bench 4–6 feet high. Because soil can collapse after excavating the bench, excavate only as much as you can complete within the same work shift.
2. Drill holes (the number of holes and their distance apart depend on the site) measuring 6–8 inches in diameter in soil or 3–4 inches in rock, angled 15 degrees below the horizon.
3. Fill holes with ready-mixed grout soon after drilling.
4. Insert nails immediately after grouting. Nails should be equipped with centralizers and long enough to penetrate the excavation failure plane.
5. Install horizontal and vertical drain strips on the facing to control seepage and eliminate hydrostatic pressure buildup.
6. Cover face with reinforced steel.
7. Apply shotcrete (concrete applied with a hydraulic hose) to the face.
8. Fit steel plate and anchor nut on protruding nails before the shotcrete sets.
9. Repeat steps 1–8 through the height and length of wall.
10. Apply final facing.

For more detailed information, contact Curtis Monk, division bridge engineer with FHWA, Iowa Division, 515-233-7320, curtis.monk@fhwa.dot.gov.



Photos (including cover photo) courtesy of Curtis Monk, FHWA Iowa Division

